

AERODROME/HELIPORT  
CHART - ICAO

05° 17' 44" N  
100° 16' 20" E


ELEV 3 M

TWR 121.1
SMC 121.6
121.9
ATIS 126.4

PENANG/PENANG  
INTERNATIONAL AIRPORT

RWY	DIRECTION	THR	BEARING STRENGTH
04	042° T	05° 17' 09.42" N 100° 16' 00.14" E	PCN 93/F/A/W/T ASPHALT
22	222° T	05° 18' 30.25" N 100° 17' 13.36" E	
HS1 CAUTION-VEHICLE CROSSING APRON TAXIWAY HS2 CAUTION-MULTIPLE AIRCRAFT GROSSING HS3 AIRCRAFT CROSSING RWY TO TWY J MUST HOLD SHORT AT TWY B			

ANNUAL RATE OF CHANGE 53"E  
ELEVATIONS AND DIMENSIONS  
IN METERS  
BEARINGS ARE MAGNETIC



CHANGES : MAGNETIC VARIATION  
RWY 04 PRECISION APPROACH CAT 1 LIGHTING SYSTEM  
RWY 22 SIMPLE APPROACH LIGHTING SYSTEM SINGLE SOURCE